




	B2 2101 16		B2 2615 12
	Bush for Lifting Pins		Air Pin
	B2 2305 16		B2 2615 12a
	Gage, Hardened		Air Pin
	B2 2305 17		B2 2625 11
	Gage, Hardened		Retainer
	B2 2305 22		B2 2625 11
	Gage with Sensor, Hardened		Support Plate
	B2 2305 22		B2 2705 11
	Gage for Sensor		Stop Block
	B2 2305 24		B2 2705 11
	Gage for Sensor, Hardened		Stop Block
	B2 2305 24		B2 2708 11
	Gage with Panel Position Sensor, Hardened		Spacer
	B2 2506 12		B2 2709 11
	Hook for Chute		Backing Plate
	B2 2604 12		B2 2715 11
	Air Pin		Locating Cone

	B2 2715 11		B2 2960 12
	Shim		Wear Plates, Self-lubricating
	B2 2715 14		B2 2960 12
	Locating Cone		Wear Plates, Steel
	B2 2715 14		B2 2961 11
	Shim		Wear Plates, Self-lubricating
	B2 2717 12a / B2 2717 13		B2 2961 11
	Spacer Plates, Toothed with Adjusting Plate		Wear Plates, Steel
	B2 2904 9		B2 2975 11
	Retainer		Wear Strip with Two Slide Surfaces
	B2 2904 11		B2 2978 20
	Retaining Bolt		V Driver Sets with Replaceable Inserts with Positive Return
	B2 2920 1		B2 2978 21
	Guide Post		V Driver, Self-lubricating
	B2 2920 1		B2 2978 21
	Washer		V Driver, Steel
	B2 2933 1		B2 2978 23
	Bush Self-lubricating		Shim Plate for V Driver

	B2 2983 11		B2 4010 1
	Toe Clamp		Backing Plate
	B2 3001 19		B2 4010 2
	Slide Stop Block		Backing Plate
	B2 3001 21		B2 4068 2
	Slide Stop Block		Locating Pin
	B2 3001 21		B2 4069 1
	Anti-Shock		Key
	B2 3001 23		B2 5601 11
	Slide Stop Block		Lifting Pins
	B2 3001 23		B2 5602 11
	Anti-Shock		Lifting Brackets with Rope Stop Safety
	B2 3602 15		B2 5602 12
	Shim		Lifting Pins
	B2 3602 15		B2 5605 11
	Visual Locator Setting Punch		Lifting Brackets with Pins
	B2 3765 1		B2 5605 12
	Key		Lifting Pins

BMW

Parts for BMW

			
	B2 5702 12		
	Pad Retainer Pins		
			
	B2 6201 11		
	Washer		
			
	B2 6201 12		
	Spacer Tubes		
			
	B2 6202 1		
	Buffer		
			
	B2 6202 1		
	Washer		
			
	B2 6202 1		
	Washer		
			
	B2 6202 13		
	Washer		
			
	B2 2101 16		
	Bush for Lifting Pins		