

FCA



Parts for FCA

			
	010.90.05		025.90.05
	Stamp		Ball Carriers
			
	010.90.05		025.90.35
	Backing Plate		Coil Guide Roller
			
	010.90.10		025.90.40
	Stamp		Coil Guide Roller
			
	010.90.50		025.90.45
	Visual Locator Punch		Roller Group
			
	010.90.55		025.90.55
	Adjustment Plate		Steel Roller
			
	010.90.60		025.90.70
	Key		Lifter Stop
			
	010.90.61		025.90.80
	Key		Stripper for Blanking Dies
			
	010.90.65		025.90.85
	Metric Master Keys		Roller Stock Lifter
			
	010.90.85		025.90.90
	Locating Cone		Spring Group

FCA

Parts for FCA

			
	030.90.05		030.90.180
	Compensation Block		Positive Return Plates, Steel
			
	030.90.10		040.90.05
	Spacer Plates, Toothed with Adjusting Plate		Flange Lifter
			
	030.90.15		040.90.10
	Pre-Centering Plate		Flange Lifter
			
	030.90.20		045.90.90
	Air Pins		Key
			
	030.90.25		050.90.65
	Bush, Steel		Distance Plates for Wear Plates
			
	030.90.40		050.90.70
	Gage		Wear Plates Self-lubricating
			
	030.90.41		050.90.75
	Gage, Hardened		Wear Plates, Steel
			
	030.90.45		050.90.80
	Gage for Sensor, Hardened		Gib Plates Steel
			
	030.90.165		050.90.85
	Air Relief Tubing		Gib Plates Steel Self-lubricating

			
	050.90.90		050.90.125
	Wear Plates, Steel		Cam Dwell Wear Plates
			
	050.90.95		050.90.125
	Wear Plates, Steel		Cam Dwell Wear Plates, Self-lubricating
			
	050.90.100		050.90.130
	V Driver Sets with Replaceable Inserts with Positive Return		Cam Dwell Wear Plates
			
	050.90.100		050.90.130
	Replaceable Wear Plates Self-lubricating		Cam Dwell Wear Plates, Self-lubricating
			
	050.90.101		050.90.131
	V Driver Sets with Replaceable Inserts with Positive Return		Shim Plate
			
	050.90.105		050.90.135
	V Driver, Steel		Adjustment Plate
			
	050.90.110		050.90.140
	V Driver, Self-lubricating		Cam Dwell Wear Plate
			
	050.90.115		050.90.145
	Distance Plates for V Drivers		Cam Dwell Wear Plate
			
	050.90.120		050.90.150
	L Shaped Wear Plates, Self-lubricating		Fork Pawl


FCA

Parts for FCA

			
	050.90.177		065.90.85
	Positive Return Plates, Steel		Guide Bushes with Collar, Self-lubricating
			
	050.90.200		065.90.90
	Stop Block		Toe Clamp
			
	050.90.205		065.90.95
	Slide Stop Block		Guide Bushes with Collar, Self-lubricating
			
	065.90.05		065.90.96
	Guide Pin Pad Retainer Assembly		Guide Bushes with Collar, Self-lubricating
			
	065.90.30-35-40-45		065.90.100
	Retainer Bolts		Toe Clamp
			
	065.90.65		065.90.102
	Shock Absorber for Pad Retainer Pins		Toe Clamp
			
	065.90.70		065.90.115
	Guide Posts		Retainer Plate for Guide Pins
			
	065.90.75		065.90.120
	Guide Posts		Wear Plates, Self-lubricating
			
	065.90.80		065.90.120
	Guide Posts		Wear Plates, Steel

FCA

Parts for FCA

			
	065.90.125		080.90.25
	Distance Plate for Wear Plates		Lifter
			
	065.90.130		080.90.60
	Pad Retainer Pins		Coupling Clamps
			
	065.90.190		080.90.65
	Locating Pins		Union Nut
			
	065.90.195		080.90.70
	Cylindrical Stop Block		Union Nut
			
	065.90.200		080.90.75
	Retainer Plate		Sleeve
			
	075.90.45		080.90.80
	Spring Plunger		Guide Post
			
	075.90.110		080.90.90
	Pressure Plate		Elastomer Cap
			
	075.90.115		085.90.135
	Pressure Plate		Coupling Plates
			
	075.90.120		085.90.140
	Pressure Plate		Coupling Nut

	095.90.10		095.90.75
	Threaded Steel Insert		Lifting Pins
	095.90.20		STQ 40005
	Elastomer Springs		Bracket for Clamps
	095.90.25		STQ 40005
	Pins for Elastomer Springs		Plates for Bracket
	095.90.30		STQ 40005
	Lifting Pins		Plates for Bracket
	095.90.35		STQ 40005
	Lifting Pins		Plates for Bracket
	095.90.40		STQ 40005
	Bush for Lifting Pins		Plates for Bracket
	095.90.60		STQ 40007
	Lifting Brackets with Pins		Visual Locator
	095.90.60		STQ 40010
	Lifting Brackets with Pins		Locating Block
	095.90.75		STQ 40011
	Lifting Pins		Stop Blocks

FCA

Parts for FCA

			
	STQ 40013		
	Key		