

OPEL

Parts for OPEL

			
	F33010001 ~ 0049		F33040024 ~ 0035
	Guide Posts		Wear Plates, Self-lubricating
			
	F33010038 ~ 0058		F33040036 ~ 0044
	Guide Posts		Wear Plates, Steel with Self-lubricating
			
	F33010060 ~ 0076		F33040085 ~ 0112
	Guide Posts		Wear Plates, Self-lubricating
			
	F33020019 ~ 0026		F33040090 ~ 0093
	Guide Bushes with Collar, Self-lubricating		V Driver, Self-lubricating
			
	F33020036 ~ 0037		F33040100 ~ 0111
	Toe Clamp		L Shaped Wear Plates, Self-lubricating
			
	F33030001 ~ 0040		F33040139 ~ 0147
	Matrix Retainer		Cam Dwell Wear Plates, Steel
			
	F33030041 ~ 0070		F33040148 ~ 0156
	Distance Plate		Cam Dwell Wear Plates, Self-lubricating
			
	F33040000 ~ 0138		F33040165 ~ 0183
	Wear Plates, Self-lubricating		Wear Plates, Steel with Self-lubricating
			
	F33040121 ~ F33050012		F33040287 ~ 0289
	Wear Plates, Steel		Cam Driver Plates , Steel

OPEL

Parts for OPEL

			
	F33040288 ~ 0290		F33150011 ~ 0015
	Cam Dwell Self-lubricating		Pad Retainer Pins
			
	F33040305 ~ 0320		F33150037 ~ 0044
	Wear Plates, Self-lubricating		Aerial Pin
			
	F33050018 ~ 0026		F33150045 ~ 0048
	Wear Plates, Steel		Air Pin
			
	F33050069 ~ 0072		F33150060 ~ 0061
	V Driver, Steel		Locating Pins
			
	F33050081 ~ 0083		F33150087 ~ 0091
	V Driver, Self-lubricating		Lifting Pins
			
	F33050084 ~ 0086		F33160002
	V Driver, Steel		Pressure Plate
			
	F33050087		F33160106 ~ 0107
	V Driver, Steel		Washer
			
	F33050088		F33160108 ~ 0204
	V Driver, Self-lubricating		Distance Plates
			
	F33050089 ~ 0107		F33160157 ~ 0188
	Wear Plates, Steel		Shim Plates

OPEL

Parts for OPEL

			
	F33160218		F33190035 ~ 0036
	Fastening Plates		Spacer
			
	F33160230 ~ 0250		F33200009 ~ 0033
	Shim Punch Retainer		Key
			
	F33160226 ~ 0344		F33260004 ~ 0397
	Block		Gage
			
	F33160345 ~ 0371		F33260014 ~ 0024
	Block		Acceleration Cam
			
	F33180007 ~ 0012		F33260026 ~ 0043
	Washer		Guide
			
	F33180020 ~ 0021		F33260029
	Distance Plates		Disk
			
	F33190003 ~ 0038		F33260030
	Locating Cone		Washer
			
	F33190005 ~ 0026		F33260203 ~ 0205
	Spacer		Front Gages
			
	F33190031 ~ 0034		F33260223 ~ 0342
	Bottoming Block		Slide Stop Block

OPEL

Parts for OPEL

	F33280001		F33910002 ~ 0003
	Coiler for Electrical Wires		Air Coupling Bracket
	F33290041		F33910043
	Counter Pressure Plate		Retainer for Stamps
	F33290043 ~ 0164		F33910044
	Stamp		Retainer for Stamps
	F33290063		F33910110 ~ 0115
	Stamp		Bush for Lifting Pins
	F33290068		J06910069 ~ 0070
	Visual Locator Punch		Sensor Mounting Bracket
	F33310014 ~ 0022		M16045182 ~ 184
	Clamping Flange for Gas Springs		Shock Absorber
	F33310023 ~ 0024		M36600070 ~ 0073
	Urethane Spring Retainer		Washer
	F33310029 ~ 0036		
	Clamping Flange for Gas Springs		
	F33910001		
	Air Coupling Bracket		