Części do maszyn Fanuc — Diamond Guide

	No.	Size	Description	Machine	Spec.	According to No.
	F101	0,205	Diamond Guide Upper	O,P,Q,R,T,W Series	Manual	A290-8021-X765
		0,255				A290-8021-X766
		0,305				A290-8021-X767
	F102	0,205	Diamond Guide Lower	O,P,Q,R,T,W Series	Manual	A290-8021-X775
		0,255				A290-8021-X776
		0,305				A290-8021-X777
	F102T	0,205	Diamond Guide Lower	O,P,Q,R Series	Manual For Big Taper	A290-8021-Y775
		0,255				A290-8021-Y776
		0,305				A290-8021-Y777
	F103	0,205	Diamond Guide Upper	T,W Series	AWF	A290-8032-X775
		0,255				A290-8032-X776
		0,305				A290-8032-X777
	F103T	0,205	Diamond Guide Upper	O.P.Q.R series	Manual For Big Taper	A290-8021-Y765
		0,255				A290-8021-Y766
		0,305				A290-8021-Y767
	F104	0,205	Diamond Guide Lower	T,W Series	AWF	A290-8032-X735
		0,255				A290-8032-X736
		0,305				A290-8032-X737
	F104T	0,205	Diamond Guide Lower	T,W Series	Manual For 30°Taper	A290-8032-X765
		0,255				A290-8032-X766
		0,305				A290-8032-X767
	F105	0,205	Diamond Guide Lower	K,M,N,L Series	AWF	A290-8018-X443
		0,255				A290-8018-X444
		0,305				A290-8018-X445
	F106	0,205	Diamond Guide Upper & Lower	K,M,N,L Series	Manual DU300A Power supply	A290-8011-X833
		0,255				A290-8011-X834
		0,305				A290-8011-X835
	F107	0,205	Diamond Guide Upper	K,M,N,L Series	AWF	A290-8018-X463
		0,255				A290-8018-X464
		0,305				A290-8018-X465
	F108	0,205	Diamond Guide Upper & Lower	K,M,N,L Series	Manual DU60C Power supply	A290-8011-X753
		0,255				A290-8011-X754
		0,305				A290-8011-X755
	F110	0,205	Diamond Guide Upper	α-A,B,C,iA,iB Series	Manual	A290-8101-X733
		0,255				A290-8101-X734
		0,305				A290-8101-X735
	F110T	0,205	Diamond Guide Upper	α-A,B,C,iA,iB Series	Manual For 45°Taper	A290-8103-X705
		0,255				A290-8103-X706
		0,305				A290-8103-X707

Części do maszyn Fanuc — Diamond Guide

	No.	Size	Description	Machine	Spec.	According to No.
	F111	0,205	Diamond Guide Lower	α-A,B,C,iA,iB Series	Manual	A290-8101-X743
		0,255				A290-8101-X744
		0,305				A290-8101-X745
	F111T	0,205	Diamond Guide Lower	α-A,B,C,iA,iB Series	Manual For 45°Taper	A290-8109-X715 (A290-8103-X715)
		0,255				A290-8109-X716 (A290-8103-X716)
		0,305				A290-8109-X717 (A290-8103-X717)
	F112	0,055	Diamond Guide Upper	α-A,B,C,D, iA,iB,iC,iD,Level Up (iD2),iE,CiA Series	AWF	A290-8112-Y702
		0,075				A290-8112-Y703
		0,105				A290-8092-X702
		0,155				A290-8092-X704
		0,205				A290-8092-X705
		0,255				A290-8092-X706
		0,305				A290-8092-X707
	F112T	0,105	Diamond Guide Upper	α-A,B,C,D, iA,iB,iC,iD Series	AWF For 45°Taper	A290-8104-X702
		0,155				A290-8104-X704
		0,205				A290-8104-X705
		0,255				A290-8104-X706
		0,305				A290-8104-X707
	F113	0,105	Diamond Guide Lower	α-A,B,C,D iA,iB,iC,iD Series	AWF	A290-8110(8092)-X712
		0,155				A290-8110(8092)-X714
		0,205				A290-8110(8092)-X715
		0,255				A290-8110(8092)-X716
		0,305				A290-8110(8092)-X717
	F113-1	0,055	Diamond Guide Lower (Double Ceramic)	α-0iC, 0iD,1iD, Level Up (iD2), α-iE ,α-CiA Series	AWF	A290-8119-Y711
		0,075				A290-8119-Y712
		0,105				A290-8119-Y713
		0,155				A290-8119-Y714
		0,205				A290-8119-Y715
		0,255				A290-8119-Y716
		0,305				A290-8119-Y717
	F113T	0,105	Diamond Guide Lower	α-A,B,C,D iA,iB,iC,iD Series	AWF For 45°Taper	A290-8110-Z712
		0,155				A290-8110-Z714
		0,205				A290-8110-Z715
		0,255				A290-8110-Z716
		0,305				A290-8110-Z717
	F114	0,052	Finish Cut – Diamond Guide Upper	α-0iC, 0iD,1iD, Level Up (iD2), α-iE ,α-CiA Series	AWF High Accuracy Type	A290-8114-Y702
		0,072				A290-8114-Y703
		0,102				A290-8104-Y702
		0,152				A290-8104-Y704
		0,202				A290-8104-Y705
		0,252				A290-8104-Y706
		0,302				A290-8104-Y707
	F114/30T	0,205	Finish Cut - Diamond Guide Upper (Ceramic)	α-iC, iCP, iD Series	AWF For 30°Taper	A290-8114-Z725 (PCD) A290-8112-Z725 (Ruby)
		0,255				A290-8114-Z726 (PCD) A290-8112-Z726 (Ruby)
	F114/45T	0,205	Finish Cut - Diamond Guide Upper (Ceramic)	α-iC, iCP, iD Series	AWF For 45°Taper	A290-8112-Z705 (Ruby)
		0,255				A290-8112-Z706 (Ruby)
	F115	0,102	Finish Cut - Diamond Guide Lower	α-0iC, 0iD,1iD Series	AWF High Accuracy Type	A290-8104-Y712
		0,152				A290-8104-Y714
		0,202				A290-8110-Y715
		0,252				A290-8110-Y716
		0,302				A290-8110-Y717

Części do maszyn Fanuc — Diamond Guide

	No.	Size	Description	Machine	Spec.	According to No.
	F115-1	0,052	Finish Cut – Diamond Guide Lower (Double Ceramic)	Level Up (iD2), α-iE ,α-CiA Series	AWF High Accuracy Type	A290-8119-Y701
		0,072				A290-8119-Y702
		0,102				A290-8119-Y703
		0,152				A290-8119-Y704
		0,202				A290-8119-Y705
		0,252				A290-8119-Y706
		0,302				A290-8119-Y707
	F115/30T	0,21	Finish Cut – Diamond Guide Lower (Ceramic)	α-iC, iCP, iD Series	AWF For 30°Taper	A290-8114-Z735 (PCD) A290-8112-Z735 (Ruby)
		0,26				A290-8114-Z736 (PCD) A290-8112-Z736 (Ruby)
	F115/45T	0,21	Finish Cut – Diamond Guide Lower (Ceramic)	α-iC, iCP, iD Series	AWF For 45°Taper	A290-8112-Z715 (Ruby)
		0,26				A290-8112-Z716 (Ruby)
	F115-1 /45T	0,21	Finish Cut – Diamond Guide Lower (Ceramic)	Level Up (iD2), α-iE ,α-CiA Series	AWF For 45° Taper	A290-8119-Z739 (Ruby)
		0,26				A290-8119-Z740 (Ruby)
	F120		Sub die guide Upper	α-A,B,C,iA,iB Series	AWF	A290-8110-Y726 (A290-8102-Y726)
	F120-1		Sub die Seat Upper	α-A,B,C,iA,iB Series	AWF	A290-8110-X727 (A290-8102-X727)
	F121		Sub die guide Lower	α-A,B,C,iA,iB Series	AWF	A290-8110-X774
	F122		Ruby Guide Upper	α-A,B,C,iA,iB Series	AWF	A290-8101-X753
	F123		Die Guide Upper	W Series		A290-8037-X645
	F124	1,0	Sub Die Guide Lower	α-A,B,C,iA,iB,iC,iD Series	AWF	A290-8110-Y774
		0,5				A290-8112-X774
	F125-1	1,5	Jet Nozzle Upper	α-A,B,C,iA,iB,iC,iD, iE, CiA Series	AWF	A290-8102-Y756
	F125-2	0,5				A290-8102-Y757
	F125-3	1,8				A290-8102-Y754
	F125-4	0,8				A290-8102-Y755
	F125-5	1,0				A290-8102-Y761

Części do maszyn Fanuc — Diamond Guide

	No.	Size	Description	Machine	Spec.	According to No.
	F126		Nozzle Base Upper	α-B	AWF	A290-8102-X723
	F127		Nozzle Base Upper	α-C,iA,iD		A290-8110-Y723
	F128	0,3	Guide Upper	α-A,B,C,iA,iB,iC,iD Series	AWF	A290-8104-X620
		0,5				A290-8102-X620
	F129	8,0	Jet Nozzle Upper	α-A,B,C,iA,iB,iC,iD Series	AWF 30° Taper	A290-8112-Y759
	F129-1	6,0	Jet Nozzle Upper	α-A,B,C,iA,iB,iC,iD Series	AWF 20° Taper	A290-8112-Y758
	F130	1,0	Sub Die Guide Upper	α-iD Series	AWF	A290-8116-X726
	F130-1	L=14.0mm	Sub Die Spring Upper	α-iC,iD Serie	AWF	A290-8110-Y728
	F130-2	L=12.5mm		α-C Serie		A290-8102-X728
	F131		AWF Nozzle Upper	α-A,B,C,iA,iB,iC,iD Series	AWF	A290-8102-X622
	F132		Guide Upper	α-A,B,C,iA,iB,iC,iD Series	AWF	A290-8102-X615
	F133		Jet Nozzle Upper	α-A,B,C,iA,iB,iC,iD Series	AWF	A97L-0201-0490 #136
	F134		Plate Spring Upper	α-0iA,1iA,0iB,1iB, 0iC, 1iC Series	AWF	A290-8102-X684
	F135		Elektrode Upper	α-Level Up (iD2), α-iE ,α-CiA Series	AWF	A290-8119-X693
	F136		Slide Plate Upper	α- Series	AWF	A290-8102-X738

Części do maszyn Fanuc — Power Feed Contact

	No.	Size	Description	Machine	Spec.	According to No.
	F002	16x6x6.3	Power Feed Contact Upper & Lower	O,P,Q,R,T,W		A97L-0126-0001/15S1P
	F004	16x6.3x6	Power Feed Contact Lower	W(1,2,3,4)	AWF	A290-8032-Z882
	F005	2.8x7.7x23	Power Feed Contact Upper & Lower	α-A,B Series	Manual AWF (polished)	A290-8101-X750
	F006	4x12x23	Power Feed Contact Upper & Lower	α-C, iA,iB,iC,iD Series	Manual AWF (polished)	A290-8110-X750
	F006-1	4x12x30	Power Feed Contact Upper & Lower	α-C, iA,iB,iC,iD Series	Manual AWF Long Length (polished)	A290-8110-X750-L
	F007	15x6x6	Power Feed Contact Upper	W0	(polished)	A290-8048-X759
	F008	4x10x26	Power Feed Contact Lower	α-Level Up (iD2), α-iE ,α-CiA Series	AWF (polished)	A290-8119-Z780
	F008-1	4x10x30	Power Feed Contact Lower	α-iE ,α-CiA Series	AWF (polished)	A290-8119-Z780-L

Części do maszyn Fanuc — Water Nozzle

	No.	Size	Description	Machine	Spec.	According to No.
	F201/4	4 ø	Water Nozzle Upper & Lower	O,P,Q,R,T,W Series	Manual	EDM-Deutschland Original
	F201/5.5	5,5 ø	Water Nozzle Lower	O,P,Q,R,T,W Series	Manual	A290-8021-Y745
	F202/3	3 ø	Water Nozzle Lower	O,P,Q,R,T,W Series	Manual	EDM-Deutschland Original
	F202/4	4 ø	Water Nozzle Lower	O,P,Q,R,T,W Series	Manual	EDM-Deutschland Original

Części do maszyn Fanuc — Water Nozzle

	No.	Size	Description	Machine	Spec.	According to No.
	F202/5.5	5 ø	Water Nozzle Lower	O,P,Q,R,T,W Series	Manual	A290-8021-Y755
	F204	5,5 ø	Water Nozzle Lower	W-1,2,3,4	AWF	A290-8037-X879
	F205	5,5 ø	Water Nozzle Upper	W-1,2,3,4	AWF	A290-8032-Y611
	F206		Nozzle Cap Upper & Lower		For F201/F202	A290-8021-V722
	F206-1		Nozzle Cap Upper & Lower		Stainless Steel For F201/F202	EDM-Deutschland Original
	F207/7	7 ø	Water Nozzle Upper	W-0	Manual	A290-8048-X771
	F208/7	7 ø	Water Nozzle Lower	W-0	Manual	A290-8048-X772
	F209/2	2 ø	Water Nozzle Upper	α-A,B,C,iA,iB,iC Series	Manual	A290-8111-X772 (A290-8109-X772)
	F209/4	4 ø	Water Nozzle Upper	α-A,B,C,iA,iB,iC Series	Manual	A290-8111-X774 A290-8109-X774 for C A290-8101-X775 for A,B
	F209/6.5	6,5 ø	Water Nozzle Upper	α-A,B,C,iA,iB,iC Series	Manual	A290-8111-X776 A290-8109-X776 for C & A290-8101-X776
	F210		Nozzle Holder Lower	α-A,B,C,iA,iB,iC Series	Manual	A290-8101-X755
	F211/2	2 ø	Water Nozzle Lower	α-A,B,C,iA,iB,iC Series	Manual	A290-8103-X774
	F211/4	4 ø	Water Nozzle Lower	α-A,B,C,iA,iB,iC Series	Manual	A290-8101-X774 A290-8101-X756 for A.B.C.
	F211/6.5	6,5 ø	Water Nozzle Lower	α-A,B,C,iA,iB,iC Series	Manual	A290-8101-X756

Części do maszyn Fanuc — Water Nozzle

	No.	Size	Description	Machine	Spec.	According to No.
	F212/2	ø 2	Water Nozzle Upper	α-A,B,C,iA,iB,iC,iD, α-Level Up (iD2), α-iE ,α-CiA Series	AWF	A290-8104-X775
	F212/4	ø 4				A290-8102-X775
	F212/6.5	ø 6,5				A290-8102-X751
	F212/12	ø 12				A290-8102-X752
	F213/2	ø 2	Water Nozzle Lower	α-A,B,C,iA,iB,iC,iD Series	AWF	A290-8104-X774
	F213/4	ø 4				A290-8102-X774
	F213/6.5	ø 6,5				A290-8102-X771
	F213/12	ø 12				A290-8102-X772
	F214/2	ø 2	Water Nozzle Lower	α-Level Up (iD2), α-iE ,α-CiA Series	AWF	A290-8119-Z791
	F214/4	ø 4				A290-8119-Z786
	F214/6.5	ø 6,5				A290-8119-Z787
	F214/12	ø 12				A290-8119-Z788
	F214-O		Lock Nut Ring Lower	α-Level Up (iD2), α-iE ,α-CiA Series	AWF (for F214)	A98L-0001-0347/ S36-W
	F218	6,5 ø	Water Nozzle Upper	α-C Series	Manual	A290-8109-X776

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F301	92x75x10 mm	Isolator plate Lower	L	Manual	A290-8005-X722
	F302	75x62x10 mm	Isolator plate Lower	O,P,Q,R,T		A290-8021-X709
	F303	73.5x39x12 mm	Isolator plate Lower	W Series	AWF	A290-8032-X334
	F304	51x33x29 mm	Isolator plate Upper	O,P,Q,R,W		A290-8021-X602
	F305	40x40x34 mm	Isolator plate Upper	α-A,B Series		A290-8101-X509
	F306	Ø 72 mm	Isolator plate Lower	α-A,B,C Series		A290-8101-X312
	F306-1	Ø 72 mm	Isolator plate Lower	α-C,iA,iB Series		A290-8110-Y312

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F307	75x56x66 mm	Guide Base Lower	α-A,B Series	for F404A	A290-8101-X761
	F308	81x56x66 mm	Guide Base Lower	α-C,iA,iB,iC Series	for F404	A290-8110-Y761
	F308-1		Guide Base Cover Lower	α-C,iA,iB,iC Series		A290-8110-Y780
	F309		Guide Block	α-C,iA,iB Series		A290-8110-X721
	F310	70x50x19 mm	Isolator plate Upper	α-0iD,0iDP Series		A290-8111-Y526
	F311A		Isolator plate Upper	α-1iD Series		A290-8110-X600
	F311B		Isolator plate Upper	α-iC Seried		Á290-8116-Y546
	F312	56x40x15 mm	Guide Block Lower	α-0iD,0iDP Series	AWF	A290-8119-X764
	F313	56x40x28 mm	Guide Block Lower	α-1iD Series	AWF	A290-8120-X764
	F314		Guide Block Lower	α-0iE, 1iE Series		A290-8120-Z764
	F315		Guide Block Lower	α-1iE, CiA600-Series	AWF	A290-8120-Z764

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F400		Bearing		For F401 & F402	A97L-0001-0670/1260Z
	F401C	49×6.5×6	Roller Lower	W Series	Ceramic	A290-8004-X713
	F402C	64×6.5×6	Roller Lower	W Series	Ceramic	A290-8006-X707
	F403	40x40x25	Guide Base Lower	α-A,B Series	Stainless Steel	A290-8103-X762
	F403-1	40x40x19				A290-8102-X762 A290-8104-X762
	F404	69x51x20 mm	Lower guide block A	α-C,iA,iB,iC Series	Manuell AWF Stainless Steel (for F308)	A290-8110-X770
	F404A	59x49x20 mm	Lower guide block A	α-A,B Series	Manual AWF Stainless Steel (for F307)	A290-8110-X770
	F404C		Lower guide block A	α-A,B Series	Manuell AWF (Ceramic) (for F307)	A290-8110-X770-C
	F404-1		Lower Roller	α-A,B,C,iA,iB,iC Series	Manual AWF (Ceramic)	A290-8101-X765
	F405		Feed Ceramic Guide Feed Section	α-A,B,C Series	Manual AWF (Plastic)	A290-8101-X394
	F405C		Feed Ceramic Guide Feed Section	α-A,B,C Series	Manual AWF (Ceramic)	A290-8101-X394
	F406		Pinch Roller Feed Section	α-A,B Series	Manual AWF (Ceramic)	A290-8101-Z382
	F407		Feed Roller Feed Section	α-A,B Series	Manual AWF (Ceramic)	A290-8101-Z383
	F408		Feed Wire Guide Feed Section	α-A,B,C Series	Manual AWF (Plastic)	A290-8102-X393
	F408-1		Shut off Guide Feed Section		Manuell AWF (Acryl)	A290-8112-X393

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F409	Ø 140	Brake Shoe Upper	α-A,B,C,iA,iB Series	Manual AWF	A290-8101-X371
	F409-1		Brake Shoe Upper	O,P,Q,R,T,W Series	Manual	A290-8011-V352
	F409-2		Breake Shoe Upper	W-Series	AWF	A290-8039-V352 (A290-8039-V354)
	F410		Pinch Roller Feed Section	α-C Series	Manual AWF (Ceramic)	A290-8110-X382
	F410BE		Pinch Roller Feed Section	α-C Series	Manual AWF (Ceramic) complete	A290-8110-V384 #STD
	F411		Feed Roller Feed Section	α-C Series	Manual AWF (Ceramic)	A290-8110-X383
	F412		Guide Base Lower	α-C,iA,iB, 0iC, 1iC Series	Manual AWF Stainless	A290-8110-Y762
	F412-1		Guide Base Lower	α-C Series	Manual AWF Stainless	A290-8110-X762
	F412-2		Guide Base Lower	α-iD, iE α-CiA Series	AWF Stainless	A290-8120-X763
	F412-3		Powerfeed Contact Seat Feed Section	α-iD, iE α-CiA Series	AWF	A290-8123-Z770
	F413		Pinch Roller Feed Section	α-0iA,1iA,0iB,1iB, 0iC, 1iC Series	Manual AWF (Ceramic)	A290-8112-X382
	F413-1		Gear Feed Section	α-0iA,1iA,0iB,1iB, 0iC, 1iC Series		A290-8112-X362
	F414		Feed Roller Feed Section	α-0iA,1iA,0iB,1iB, 0iC, 1iC Series	Manual AWF (Ceramic)	A290-8112-X383
	F414-1		Gear Feed Section	α-0iA,1iA,0iB,1iB, 0iC, 1iC Series	Manual AWF (Ceramic)	A290-8112-X363

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F414-2		Cover Feed Section	α-0iA,1iA,0iB,1iB, 0iC, 1iC Series		A290-8112-X361
	F415		Shaft	α-iA,iB Series	for F413	A290-8112-X378
	F416		Shaft	α-iA,iB,iC Series	for F414	A290-8112-X373
	F417		Shaft	α-iA,iB,iC Series	for F411	A290-8110-X373
	F418		Shaft	α-A,B Series	for F404-1 + F501	A290-8101-X766
	F419		Shaft	α-C,iA,iB,iC Series	for F404-1 + F501	A290-8110-X766
	F419-1		Shaft	α-iD, iE α-CiA Series	for F424 + F501	A290-8119-X767
	F419-2		Shaft	α-iD, iE α-CiA Series	for F421	A290-8119-X378
	F419-3		Shaft	α-iD, iE α-CiA Series	for F422	A290-8119-X373
	F420		Brake Shoe Upper	α-iB,iC Series		A290-8111-X371
	F421		Pinch Roller Feed Section	α-iD, iE α-CiA Series	AWF Ceramic	A290-8119-X382
	F422		Feed Roller Feed Section	α-iD, iE α-CiA Series	AWF Ceramic	A290-8119-X383
	F422-1		Cover Feed Section	α-iD, iE α-CiA Serie		A290-8119-X361
	F422-2		Cover Feed Section	α-iD, iE α-CiA Serie	threaded	A290-8119-X362
	F423		Brake Shoe Upper	α-iD, iE α-CiA Series		A290-8119-X618

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F423-1		Detect Roller Upper	α-iD, iE Series		A290-8119-X625
	F423-2		Roller Upper	α-iD, iE Series		A290-8119-X626
	F423-3		Bearing Upper	α-iD, iE Series	For F423-1	A97L-0001-0670# LF1470ZZ
	F423-4		Wire Guide Upper	α-iD, iE Series		A290-8119-X639
	F423-5		Wire Guide Upper	α-iD, iE Series	Ceramic	A290-8119-X628
	F424		Roller Lower	α-iD, iE α-CiA Series	Ceramic	A290-8119-X766
	F424-1		Roller Seal Lower	α-iD, iE α-CiA Series		A97L-0203-0424
	F425		Wire Guide Block Lower	α-iD, iE α-CiA Series	Ceramic	A290-8119-X762
	F501		Bearing Lower	α-A,B,C,iA,iB,iC,iD Series	Manual AWF For F404-1	A97L-0001-0670/DRF2280H
	F502		Bearing Lower	α-A,B,C Series	Manual AWF For F406,F410	A97L-0201-0369/6001LLU
	F503		Bearing Lower	α-A,B Series	Manual AWF	A97L-0201-0369/6203LLU
	F504		Cutter Upper	W Series	AWF	A290-8032-X626
	F505		Screw Upper	α-0iA,1iA,0iB,iC,iD Series		A290-8110-X751
	F506		Screw Lower	α-C Series		A290-8110-X752
	F507		Cover Lower	α-C,iA,iB,iC Series	Manual AWF für F412	A290-8110-Y767

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F600		Chuck-MHZ J2 Pneumatic Parallel-gripper	α- Series	AWF	A290-8110-V607#STD (A97L-0201-0485#6D2) (A97L-0201-0937)
	F601		Rubber Chuck Upper	α-0B,1B,0C,1C Series		A290-8102-X656
	F602		Rubber Chuck Upper	α-0A,1iA,0B,1iB,iC Series		A290-8112-X656
	F603		Cutting Electrode Upper	α-0A,1iA,0B,1iB,iC Series		A290-8102-X657
	F604		Block Upper	α- Series		A290-8104-X612
	F604-1		Block Upper	α-iD Series		A290-8119-X685
	F605		Cover Upper	α- Series		A290-8102-X616
	F605-1		Cover Upper			A290-8114-X616
	F606		Pin Electrode	α- Series		A290-8104-X633
	F606-1		Pin Electrode	α-iD Series		A290-8119-X633
	F606-6		Sheet	α- iC Series		A290-8110-Y769
	F607	47/35x7	Roller Bearing Feed Section	α-0iA,1iA,0iB,1iB, iC,iD Series	for F413 F421	A97L-0201-0911 #6807
	F608	35/17x10	Ball Bearing Feed Section	α-0iA,1iA,0iB,1iB, iC,iD Series	for Shaft of F413/F414 F421/F422	A97L-0201-0910 #6003

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F609	115x 85x14mm	V-Packing	α -0 Series		A98L-0001-0972
	F609-1		Bellow Lower	α -0iD Series		A290-8119-X095
	F609-2		Bellow Lower	α -0iD Series		A290-8119-X057
	F609-3					A290-8119-X058
	F610	140x 108x14mm	V-Packing	α -1 Series		A98L-0001-0973
	F610-1		Bellow Lower	α -1iD Series		A290-8120-X092
	F610-2		Bellow Lower	α -1iD Series		A290-8120-X057
	F610-3					
	F610-4			CiA400		A290-8120-X058
	F610-5					
	F611		Float Switch	α- Series	Z-Axis	A290-8110-V165FLTW
	F614		Coupler Filter	α- iB,iC,iD,iE,CiA Series	For filter with ¾ coupling	A97L-0203-0097 #6-AF
	F615		Grease Pump	All machines	400 Gramm	A04B-0311-J026 #HGPN
	F615-1				80 Gramm	A97L-0201-0939 #HGPN
	F616	80 Gramm	Grease	All machines	NSK LR3	A98L-0001-0465#2
	F616-1	400 Gramm			NSK AS2	A98L-0004-0602#CTG-J
	F617		Feed Ceramic Guide	α-0iA,1iA,0iB,1iB, 0iC, 1iC-Series	Manuell AWF (Ceramic)	A290-8112-X394
	F617-1		Feed Ceramic Guide	α-iD, iE α-CiA Series	Manuell AWF (Ceramic)	A290-8119-X394

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F618		Winding	α-0iA,1iA,0iB,1iB, 0iC, 1iC-Series	Manuell AWF (Ceramic)	A290-8112-X391
	F618-1		Winding			A290-8119-X391
	F619		Grip	α- Series		A98L-0001-0938 #1555
	F620		Grip	α- Series		A98L-0001-0938 #1573
	F621		Strainer	α- Series		A97L-0201-0583 #4B-100S
	F622		Battery	α- Series		A98L-0031-0012
	F623	6x4x12mm	Brush	α- Series	Wire Feed Motor	A90L-0001-0468#BR
	F624		Spacer	α- Series		A290-8112-X375
	F624-1		Spacer	α- Series		A290-8112-X374
	F624-2		Spacer	α- iE α-CiA Series		A290-8119-X375
	F624-3		Spacer	α-iE α-CiA Series		A290-8119-X374
	F625		Roller	α-0iC,1iC		A290-8103-X078
	F626		Roller	α-0iC,1iC		A290-8103-X079

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F627		Swing Roller Upper	α- Series		A290-8101-X335
	F627-1		Bearing Upper	α- Series	For F627	A97L-0001-0670# 1450Z
	F628		Bearing		Special High-temperatur store	A97L-0201-0673# 6201
	F629		Valve	α- Series		A97L-0201-0770# A05PS25
	F630		Valve	α- Series		A97L-0201-0770# A05PS25X
	F631			α- Series	seal	A98L-0001-0987#17
	F632		Bushing			A290-8110-X317
	F633		Wire Cylinder Upper	α- iD, iE, α-CiA, CiB Series	PKD laminated	A290-8116-Y756
	F633-1		Cylinder Base	α-iD, iE α-CiA Series		A290-8120-Z783
	F633-2		Slide Pin Holder Upper	α-iD, iE α-CiA Series		A290-8116-Y757
	F634		Spring Tank	α-0A,0B,0C, 0iA,0iB	Stainless Steal	A97L-0201-0320 #DH10x20
	F635		Bearing Tank	α-0A,0B,0C, 0iA,0iB		A97L-0001-0670 #1650HH
	F636		Silicone Tank	100 Gramm	Seal-system	A98L-0001-0152 #45RTVS
	F637		Felt	All machines		A290-8004-X410
	F638		Sub Die Block	α- 0iC, 1iA		A290-8110-Y763

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F639		Clutch			A290-8114-V647 #COM
	F640		Electrode Shaft Lower		for Powerfeed Contact	A290-8119-Z781 A290-8120-Z781
	F641		Screw Lower			A290-8102-X739
	F642		Screw			A290-8123-Z772
	F643		Gasdamper	α-iD, iE α-CiA Series		A97L-0203-0098 #100-20
	F644		Cover			A290-8119-X765
	F645		Chuck	α- Series		A290-8102-X660
	F646		Finger			A290-8119-X691
	F647		Finger			A290-8119-X692
	F648		Chuck	α- 0iA, 1iA Series		A290-8112-X654
	F649		Holder for Airfilter		Set	A98L-0004-0093 #A
	F650		Joint Lower			A97L-0203-0464 #FTT4M5
	F651		Joint Lower			A97L-0203-0464 #FTL4M3
	F652		Joint Lower			A97L-0203-0464 #FCL4-M5

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	F653		Joint Lower			A97L-0203-0464 #FLSM5
	F654		Hinge	A- iB, iC, iD Serie		A97L-0201-0262#3

Części do maszyn Fanuc — Cable

	No.	Size	Description	Machine	Spec.	According to No.
	F612-650	L=650mm	Ground Cable	L,P,W1	Lower	EDM-Deutschland Original (please tell us the cable length and the size of the cableshoe)
	F612-800	L=800mm			Upper	
	F612-750	L=750mm		Q,T1,W2	Lower	
	F613-880	L=880mm			Upper	
	F613-880	L=820mm		R,W3	Lower	
	F613-880	L=1200mm			Upper	
	F613-910	L=910mm		W4	Lower	
	F613-1300	L=1300mm			Upper	
	F612-550	L=550mm		α-0A,0B	Lower	
	F612-810	L=810mm			Upper	
	F612-580	L=580mm		α-0C+iA	Lower	
	F613-1220	L=1220mm			Upper	
	F612-810	L=810mm		α-1-Series	Lower	
	F613-1460	L=1460mm			Upper	
	F700		Discharge Cable Lower	α- 1iD Series	Set a 4 pcs.	A290-8120-V102 #1LW
	F700-1		Discharge Cable Upper	α- 1iD Series	Set a 3 pcs.	A290-8120-V103 #1UP
	F700-2		Discharge Cable Lower	α- 0iD Serie	Set a 4 Stk.	A290-8119-V102 #0LW
	F701		Discharge Cable Lower	α- 1iE Series	Set a 5 pcs-.	A290-8120-V102 #1LWM

Części do maszyn Fanuc — Connected Parts

	No.	Size	Description	Machine	Spec.	According to No.
	Z041		Flow Meter + Cylinder	All machines		A91L-0001-0066
	Z041F		Flow Meter	All machines		A91L-0001-0229#M A91L-0001-0053
	Z041F-1		Cylinder	All machines		-

Części do maszyn Fanuc — Belt

	No.	Size	Description	Machine	Spec.	According to No.
	F0036	14 x 1112mm	Belt	FTC-W1	AWF	A290-8039-X860
	F0037	14 x 1417mm		FTC-W1	AWF	A290-8039-X861
	F0038	14 x 1315mm		FTC-W2	AWF	A290-8040-X860
	F0039	14 x 1620mm		FTC-W2	AWF	A290-8040-X861
	F0040	21 x 1645mm		FTC-W3	AWF	A290-8046-X860
	F0041	21 x 1962mm		FTC-W3	AWF	A290-8046-X861
	F0042	21 x 2080mm		FTC-W4	AWF	A290-8047-X860
	F0043	21 x 2400mm		FTC-W4	AWF	A290-8047-X861